

## GLASSWASHER HYGIENE AND MAINTENANCE

### Before Each Cycle

- Remove lemon slices and cocktail sticks – The machine is not a waste disposal unit.
- Manually remove lipstick – Most glasswashers will not remove this.
- Discard any drink residues into the sink – The wash water is only refreshed by about 20% each cycle.
- Do not wash or empty ashtrays into the machine.
- Do not interrupt or shorten the wash cycle – A full cycle will ensure good results and dry glasses.

### Daily Tasks

- Switch off machine – Do not leave switched on permanently.
- Remove basket and drain.
- Remove filters, tap out and rinse using clean water in the sink.
- Remove any debris left in the machine – broken glass, lemon, cocktail sticks etc.
- Wipe down the machine interior with a clean damp cloth – do not use washing up liquid.
- Top up chemical reservoirs.
- Leave door open / ajar when not in use for longer periods.

### Weekly Tasks

- Remove wash arms, strip down and clean.
- Wash machine internally using a chlorine based renovator chemical – if using a powder renovator ensure no residue is left in tank.
- Regenerate water softener (if fitted) – Instructions on rear.

### Other Useful Tips

- Renovate all glasses twice a month – Invisible detergent residues can build up and affect beer head.
- Renovate all new glasses – These are supplied coated in a mould release agent that will affect beer head.